



Pressure system

parts for a 20' model

- 1- plastic tank holder
- 1- plastic tank
- 1- upright stand
- 1- rubber tie strap
- 50' plastic hose
- 1- 4 bank manifold
- 6- square u-bolts
- 12- 3/8 flange nuts
- 4- cap, washer & flat seal barb fitting
- 30- plastic tie straps

- 1- Mount your upright stand (where you would like it) with 2 u-bolts & flange nuts.
- 2- Place the tank holder on top of it and fasten with 2 u-bolts & flange nuts.
- 3- Secure the plastic tank into the holder with a rubber tie strap.
- 4- Place the valve assembly onto the side of the upright stand and secure with 2 u-bolts & flange nuts.
- 5- Run a piece of hose from the tank into the top ball valve.
- 6- There are four ball valves on the assembly. One ball valve for each tube.
- 7- Start by running a hose from one of the ball valves, along the steel tubing and when you get to a fill cap, remove the fill cap and replace it with a cap, flat seal barb and washer. Cut the hose and insert into the barb. Then you start again at the ball valve, run a hose along the steel tubing and cut the hose and insert into the next tube. **It is best to not tie down the hose with plastic tie straps until you have all your hose lines in place. That way one plastic tie strap will hold down both of the hose lines on each side of the wick weeder.**
- 8- Repeat on the other side with the other two ball valves.
- 9- Remember to leave a bit of extra length where the Wick Weeder hinges.

Directions:

- Now you are ready to fill the tank with your chemical mixture.
- It is best to fill all the tubes individually first, and then once the wicks have all gotten saturated with chemical and you are ready to go wicking, then open the ball valves so the wicks will continue to remain well saturated.
- The ball valve on the top can be opened all the way but the four ball valves that feed the wick tubes do not need to be open all the way. This will avoid any dripping.
- How far you open the ball valve is up to your own discretion. If you are in a very heavy infestation of weeds you may need to open the ball valves up all the way.